

# SURF – PRO



TIME SAVER SURFACE CLEANER

## TECHNICAL DATA SHEET

Name: **The SHOWER BUSTER**

Product: Stops soap scum accumulation on all types of showers

Code: BO-4150



MADE IN CANADA



### 1.1 PRODUCT DESCRIPTION:

The shower has been formulated for two reasons: Thoroughly clean showers and baths virtually effortlessly and eliminate the use of a squeegee to wipe glass shower doors. A simple jet of water will be enough to get rid of soap residue.

### 1.2 USES:

Can be used on glass, acrylic, ceramic, chrome, bath, shower, sink.

### 1.3 CHARACTERISTIC:

- No toxic vapor. Allows application while staying in the shower.
- Create a high-performance barrier without the use of silicone.
- Delays the appearance of mold.
- Does not affect chrome the repeated application of the shower buster does not blacken this one.

**1.4 GUARANTEE:** The high quality of this product is guarantee under the descriptions available on this technical data sheet and the labels. the manufacturer guarantee is limited only on the quality of the product and to the refund price of it. this product will give total satisfaction if store and utilized in conformity with the manufacturer directives.

**1.5. NORM:** Biodegradable product - zero voc.

### SAFETY MEASURES:

Keep out of the reach of children.

### JP'S TIPS:

### TECHNICAL INFORMATION

**2.1. Chemical composition:** Biodegradable surfactant

**2.2. Container size:** 500 ml UPC code 775115041001

**2.3. Appearance:** Translucent, clear liquid with slight odor of lemon.

**2.4. Storage:** Stored in a cool and dry place.

### 2.5. Physical and chemical properties:

- Water solubility : Soluble
- PH: 8.8
- Density: 1.00-1.02
- Viscosity: N/A

### APPLICATION PROCEDURES

#### 3.1 Instructions for first use:

- Spray the shower Buster on all surfaces of the shower and leave on for a minimum of 5 minutes, wipe the surfaces with a damp cloth and if the dirt is very stubborn, reapply.
- Your shower is now clean, wait until the surfaces are completely dry, spray again on the entire surface and allow to dry
- (The Shower Buster, when drying, will leave vertical lines on your surfaces, do not worry, they will disappear when you rinse with water after your shower). That's it, the process is on.
- The duration of protection may vary with use, apply when necessary.
- After each shower, leave squeegee aside, rinse with water only.

